



**WIRE ROUTING AT BOOT LID**




**WIRE ROUTING INSIDE THE BOOT**





route wire under  
the Side-Step  
(same for the front)

### WIRE ROUTING IN THE CABIN




hide Interface Module  
in this area

tap Ground  
from here


(WHITE/BLACK)  
Unlock Signal Wire  
to tap from

### BEHIND PASSENGER-SIDE KICK PANEL






**ACTUATOR MOUNTING (VIEW FROM BOTTOM)**



**ACTUATOR LINKAGE CONNECTION**



**Wiring diagram for Boot/Trunk Release.  
Mazda 3**